Nera F77 - Brief Operating Instruction

Switching ON

1 Insert SIM card (if used).

2 Set the **Power ON/OFF** switch on the upper end of the Main Communication Unit to ON. The power indicator lights up.

3 Enter SIM code (if SIM card is used)

4 Nera F77 starts up. It automatically initializes the system and searches for the satellite.

When idle, the Nera ISDN Hand-set displays:





Making a call

1 Dial 00, country code and subscriber number, e.g.:

☞ 0 0 4 abc 7 pqrs 6 mno 7 pqrs 2 abc 4 abc 4 abc

7 pqrs 0 0 / / # A~a

For normal call
For handsfree call
For analogue G3 fax and ISDN telephones

Dial (4.8)
004767244700

- When entered, the display reads:

Calling…
004767244700

- When the remote end answers, the display reads: *The timer starts.*

Connected 09:46
004767244700

Dash separates additional dialing
Timer, minutes:seconds

2 End the call by pressing hook ON/OFF , or replacing the handset in the cradle.

Disconnected

Use DEL to modify entries: DEL pressing DEL once, erases one digit. Holding the key more than 0.5 second erases the whole number.
Use the handsfree key to toggle the loudspeaker ON/OFF.

Alternative dialing:
Press or to get the dialing tone, then dial the number as described above.

Changing Net service provider

The Net service provider can only be selected for the Ocean Region in use. The Net selection is stored in the Nera F77 memory:

1 Open the **MENU** and scroll down to **Set Network**.

☞ MENU ▼

» Sat. Search
Phone setup
Set Network
Priority Call
Serial Ports
Information

2 Scroll down to the required Net service provider:

☞ OK ▼

» 002/Stratos
004/Telenor
005/OTE
012/Xantic

3 Store the new Net service provider for the current Ocean Region:

OK

Saving data ….

NERA
enabling a wireless future

Nera F77 - Brief Operating Instruction

Nera F77 provides communication with the public telephone network via **satellite**, which requires **free line of sight**.

Four satellites are positioned stationary above **equator**. The satellites provide the coverage shown on the map below.

Nera F77 searches **any Inmarsat satellite** as default.







See also the Nera F77 User Manual. The CD enclosed with the manual contains the Nera F77 vtLite Marine monitoring and configuration program.

Doc. No. 101445 Rev. 1.1 03/04

NERA
enabling a wireless future